

Figure 1





Figure 2



Shoulder Seam

## Shirt Back

Place this Edge on Fold of Fabric

1. Each pattern piece is 1/2 of the full piece. Either fold the fabric and place the indicated edge on the fold, or make two of each of the pattern pieces and tape them on the fold line.

2. Cut out of the fabric, one full front piece, one full back piece and two full sleeves.

3. Pin front to back, right sides together and sew along the shoulder seams, using a 3/8" to 1/2" seam allowance.

4. Fold the sleeve (wrong sides together) along the indicated dashed line and hem. (figure 1)

5. Fold the sleeve in half lengthwise. Align the center line of the curved edge of the sleeve with the shoulder seam on one side of the shirt. Unfold the sleeve and carefully pin the curved edge to the arm holes of the front and back pieces (right sides together). Stitch, using a 3/8" to 1/2" seam allowance.

6. Repeat step 5 with the other sleeve.

7. Lay the pieces out flat with the right sides together, and pin side and sleeve bottom edges together. (figure 2).

8. Sew from bottom of the shirt to the sleeve, and along the hem of the sleeve in one continuous stitch. (from A to B in figure 2)


9. Repeat on the other side.

10. Turn the bottom of the shirt up (wrong sides together) 3/8" to 1/2" and hem.

11. Turn the collar line down (wrong sides together) 3/8" to 1/2" and hem.

Turn garment right side out. You now have a basic pullover shirt. Collars, buttons and other trim can be added as desired.

Be sure to align fabric carefully if you are using patterned fabric, especially stripes.



Shoulder Seam

Shirt Front

Place this Edge on Fold of Fabric